

# SHORT STUFF®

## for CASE & Cementitious Applications

### MIXING INSTRUCTIONS

#### In Water Based Systems:

- Treated grades are recommended, and should be added under high shear as early in the mix as possible.
- Untreated grades may be used if added under high shear at the same time as fillers or pigments.

#### In Solvent Based Systems:

- Only untreated grades should be used, and should be added under high shear at the same time as fillers or pigments.

#### In Dry Cementitious Mixes:

- Add directly to dry cement alone; or add to the mix last, after the cement, sand and aggregates have been fully incorporated. Do not add directly to sand.

Typical dosage ranges from 0.5 to 1.0% by total formula weight for most applications; suggested starting formulations are available on our website:

<https://www.minifibers.com/our-company/about-fibers/suggested-starting-formulations>

**MINIFIBERS, INC.**

Information in this bulletin is the best available to us and is believed to be correct. No warranty is expressed or implied regarding its accuracy on the use of the product. It is expressly understood that any technical advice or assistance that may be provided by MiniFIBERS is rendered without compensation, and MiniFIBERS assumes no obligation or liability for such advice or assistance given, or for results obtained.