

SHORT STUFF®

Suggested Starting Formulation

FIBERED FLEXIBLE SKIM COAT, GREEN FORMULA CONTAINING SHORT STUFF® HDPE E505F

<u>MATERIALS:</u>	<u>Pounds</u>
Portland Cement Type 1,2.....	500.0
MiniFIBERS' SHORT STUFF® HDPE E505F.....	4.5
Elotex Seal 80.....	1.0
Elotex FX 8300.....	10.0
EZ Spred.....	10.0
Dolomite #70 Mesh Sand.....	1250.0
	<u>1775.5</u>

Add water, and mix to a uniform consistency for at least 20 minutes. Make sure fibers are evenly dispersed throughout the mixture.

MINIFIBERS, INC.