

SHORT STUFF®

Suggested Starting Formulation

FIBERED MORTAR DRY MIX CONTAINING SHORT STUFF® HDPE E505F

<u>MATERIALS:</u>	<u>Pounds</u>
Portland Cement Type 1,2.....	564.0
MiniFIBERS' SHORT STUFF® HDPE E505F.....	6.5
S Lime.....	200.0
Simpson Mortar Admix.....	15.0
Mortar Sand.....	<u>2250.0</u>
	3035.5

Mix to a uniform consistency for at least 20 minutes. Make sure fibers are evenly dispersed throughout the mixture.

MINIFIBERS, INC.