

SHORT STUFF®

Suggested Starting Formulation

FIBERED LIME-FREE EIFS FOAM BONDER CONTAINING SHORT STUFF® HDPE E505F & POLYESTER FIBERS

<u>MATERIALS:</u>	<u>Pounds</u>
Portland Cement Type 2.....	564.00
MiniFIBERS' SHORT STUFF® HDPE E505F.....	3.00
Hexion PAV 29.....	55.00
EZ Spred.....	15.00
Simpson L/R Admix.....	100.00
MiniFIBERS' 6.0 dpf x 1/8" Polyester Fibers.....	2.25
#70 Mesh Sand.....	1400.00
	<u>2139.25</u>

Mix for at least 30 minutes or until a uniform consistency is achieved. Make sure fibers are evenly dispersed throughout the mixture. This formula does not need to be tempered; once mixed with water, it is ready to use.

MINIFIBERS, INC.